PYLE®

disc jam

Dual 600 Watt Powered Two-Way PA Speaker System w/ USB/SD Readers,
FM Radio, 3.5mm AUX Input & DJ Lights

www.pyleaudio.com

Operating Instructions

PSUFM625

Specifications

PSUFM625

*Dual Speaker (One Active, One Passive)
*6.5" Woofer And 3" Piezo Tweeter
*Heavy Duty Handles For Easy Portability
*Full Featured 3 Channel Mixer
*Two ¼" Microphone Inputs
*One 3.5mm AUX Line Input With Cable (Compatible With All Mp3 Players And Devices With Headphone Outputs)
*RCA Stereo Input And Output
*USB/SD Flash and Card Readers with Built-In FM Radio
*USB Provides 5V Charge For Smart Phones and Other Devices
*Display Screen Shows Number of Songs And Play Time And FM Radio Frequency
*Master Volume Controller
*Ported Enclosure For Added Bass Response
*35mm Speaker Stand Mount
*600 Watts Peak / 300W RMS Power @4 Ohm
*Crossover Frequency: 3.5kHz
*Woofer Magnet Weight: 8 oz.
*Sensitivity (1W/1M): 90dB
*Built In Crossover Network
*Frequency Response: 20Hz-20Khz
*Crossover Frequency: 3.5kHz
*35mm Speaker Stand Mount
*AC 110/220V Power Switch
*Dimensions: 19" (H) X 17.5" (W) X 12.6" (D)
*Weight: 22 Lbs.

Safety Notes

1. Correct power must be used to operate this unit properly, do not use any other powering options, cords or methods.

2. Carfully handle, plug and unplug the power cable when handling. Hold the plug with a firm grip and when plugging or unplugging from sockets.

3. Do not open chassis! Extermely dangerous! Do not put your hands inside the chassis. If the device begins to malfunction do not attempt to repair, unplug the unit and contact Pyle immediately.

4. Don't use volatile or dangerous chemical cleaners on the unit (like toluene, alcohol, gasoline etc.) Use gentle cleaners.

5. Keep the unit in a well ventilated environment and keep away from, direct sunlight to prevent unit from overheating.

6. Avoid the unit from moisture or rain.

Operating Controls - System Layout

① Volume Control

② Treble Control

③ Bass Control

④ Mic Volume Control

⑤ Echo Control

⑥ Mic Input Jack

⑦ Line-In/Aux Audio Input

⑧ Mode Control

⑨ Next Control

⑩ Play/Pause Control

⑪ Prev Control

⑫ USB/SD Jack

⑬ Speaker handle

⑭ Metal Corner

⑮ Tweeters

⑯ Woofer confinement

⑰ Woofer Speaker

⑱ Vent hole



Speaker Board Schematic

① Line-Out/Aux Audio Output

② Line-In/Aux Audio Input

③ Vice-Box Power OUTput

④ Fm Antenna

⑤ AC Power Supply

⑥ Power Switch

⑦ Voltage Selector Switch



disco jam

PYLE®

www.pyleaudio.com

tel: 718.535.1800 fax: 718.236.2400
1600 - 63rd StreetBrooklyn, N Y,11204